


DIAGRAM AG 1 R



PART LIST

PART NO	PART NAME	PART NO	PART NAME	PART NO	PART NAME
1080002	SPool assy	72061	Bail assy	1080110	Stoper lever spring
1080058	Main shaft	72071	Bail screw	72102	Handle sc. cap. wshr.
72038	E-Clip	1080072	Bearing plate screw	72101	Handle sc. cap
72184	Roter-nut	1080074	Bearing plate	1080112	Stoper lever
72039	Roter D washer	72088	Ball bearing	72122	Stoper lever sc.
72128	Roter nut lock screw	72095	Pinion gear	1080118	Drag "E" washer
72042	Roter	1080076	Tail shaft	1080120	Metal
72072	Kick lever	72103	O/S gear	1080122	Drag "A" washer
72078	Kick lever spring	1080078	O/S slider	1080124	Drag "B" washer
72084	Kick lever cover screw	1080080	O/S slider retainer	1080126	Drag "D" washer
72080	Kick lever cover	1080082	O/S slider screw	1080128	Drag spring
72048	Roter balance	1080084	Body	1080130	Drag nut
72056	Bail spring shaft	72108	Body bushing	1080132	Back claw spring
72053	Bail spring	72110	Drive gear	1080134	Rear drag cap
72058	Bail spring cover	72112	Adj washer	1080138	Rear drag cap sc.
72084	Bail sp. cvr. sc.	72113	Body cvr. ball bearing	72091	One way clutch
72069	Arm lever	1080096	Body cover	72094	One way clutch bush
72068	Bail washer	72117	Body cvr. sc.	72090	Bearing washer
72067	Line roller	72126	Handle assy	72131	B/Bearing bush