



PART LISTING ABU 176/276/576

EM	PART DESCRIPTION	176	276	576	ITEM	PART DESCRIPTION	176	276	576
1	Cone Assy	1101926	1101926	1101927	30	Handle Screw Washer	1101759	1101759	1101759
2	Cam Connetion Retainer Screw*2	1101731	1101731		31	Handle Cover*2	1101760	1101760	1101760
3	Snubber Support Assy	1101928	1101928		32	Clutch BB Washer	1101761	1101761	1101761
4	Rotor Swing Arm Spring*2	1101929	1101929		33	Main Gear Stand (B)	1101762	1101762	1101762
5	Rotor SEMIS	1101930	1101930		34	One Way Clutch	1101763	1101763	1101763
6	Cam Screw*2	1101735	1101735		35	Main Gear Ball Bearing(Bushing)*2	1101764	1101764	1101765
7	Connetion Spacer	1101736	1101736		36	Pinion Washer	1101766	1101766	1101766
8	Cam Connetion Retainer	1101737	1101737		37	Pinion Down Ball Bearing	1101767	1101767	1101767
9	Pick Up Pin Cam	1101738	1101738		38	Main Gear	1101947	1101947	1101947
10	Main Shaft Spring (B)	1101931	1101931		39	Main Gear Stand (A)	1101769	1101769	1101769
11	"E" Ring*2	1101740	1101740		40	Handle Connetion Retainer	1101770	1101770	1101770
13	Spool Ring	1101932	1101932		41	Handle Space Washer	1101771	1101771	1101771
14	Drag Squared Washer*2	1101933	1101933		42	Double Handle Assy	N/A	N/A	1101946
15	Drag Teflon	1101934	1101934		42	Single Handle Assy	1101773	1101773	N/A
16	Spool	1101935	1101935		43	Handle Nut Cover	1101774	1101774	1101774
17	Drag Washer (red)	1101936	1101936		44	Pinion	1101948	1101948	1101948
18	Drag Spring Washer	1101937	1101937		45	Main Shaft Sleeve	1101949	1101949	1101949
19	Drag Support	1101938	1101938		46	Main Shaft Spring (A)	1101950	1101950	1101950
20	Spool Osl.	1101939	1101939		47	Gear Box Cover	MIP	1101951	1101952
21	Pinion Up Ball Bearing	1101750	1101750		48	Thumb Button Support	1101953	1101953	1101953
22	Main Shaft Bush	1101940	1101940		49	Thumb Button Assy	1101954	1101954	1101954
23	Frame	1101941	1101941		50	Rotor Assy	1101955	1101955	1101955
24	Osl. Screw*2	1101753	1101753		51	Drag Clicker Screw	1101956	1101956	1101956
25	Drag Knob	1101942	1101942		52	Drag Clicker	1101784	1101784	1101784
26	Drag Knob Ring	1101943	1101943		53	Stand Screw *4	1101957	1101957	1101957
27	Drag Knob Ring	1101944	1101944		54	Gear Box Cover Screw*2 (A)	1101786	1101786	1101786
28	Handle Nut	1101757	1101757		55	Gear Box Cover Screw (B)	1101958	1101958	
29	Handle Screw	1101945	1101945						